

Installing Your Dish Hoodie

Step 1:

Grasp the center of the back of the cover in one hand and with your other hand pull the drawstrings to gather the fabric. With the strings to the back of the dish, slip the cover over the dish and center the image.

Step 2:

Adjust the gathered fabric on the front and back to evenly fit your dish. This is just a preliminary fitting. There will be opportunity later on to do final adjustments.

Step 3:

Holding the strings in one hand, slide the self-locking clip towards the dish to tighten the cover, making sure the clip is positioned on top of the dish bracket.

CAUTION: Be careful not to pull the dish out of alignment.

With a string in each hand, tighten the cover using a side to side pulling motion until you have a secure fit. Check the front of the cover for centering and fit, adjusting as needed. Adjust the gathered fabric for the best fit, smoothing out any wrinkles. (If you need to loosen and readjust the cover, slide the center button on the self-adjusting clip towards you to release.) When the cover is taut and positioned to your liking, finish tightening using the same side to side pulling method.

IMPORTANT: The notched weep hole at the bottom of the cover is designed to allow condensation to drain away. The top of the weep hole should be positioned at or above the bottom of the dish edge, depending on your dish size.


Step 4:

Lace the left string through the upper left red lacing hole, running the string through from the inside to outside. With the same string, run through the lower right red lacing hole from the inside to outside. Pull tight and tie a knot. Gather any excess string and tuck between the cover and dish. Repeat steps for the second string. When finished, you should have a tight, drum-like fit.


Step 1



Step 2



Step 3



Self-Locking Clip

Step 4

